

EFFECTIVE:
 JULY 1, 2008

PARTS LIST FOR DW-1Z AND DW-HZ PUMPS

<u>PART #</u>	<u>NAME OF PART</u>	QTY PER PUMP:	
		<u>DW-1Z</u>	<u>DW-HZ</u>
E-100Z	* DW-1Z SHAFT SEAL ASSEMBLY	1	0
E-100HZ	* DW-HZ SHAFT SEAL ASSEMBLY	0	1
D-3	BYPASS FLANGE	1	1
D-1	MAIN HOUSING	1	0
D-1H	MAIN HOUSING	0	1
D-2	GEAR END COVER	1	1
D-3S	MOUNTING SPACER (SHORT) W/STUD	2	2
D-3L	MOUNTING SPACER (LONG) W/STUD	2	2
D-3LH	MOUNTING SPACER FOR DW-H		2
EG-5	* DRIVE GEAR	1	0
EC-5H	* DRIVE GEAR	0	1
EG-6	* IDLER GEAR WITH BUSHING	1	0
EC-6H	* IDLER GEAR WITH BUSHING	0	1
E-9	* IDLER GEAR SHAFT	1	1
E-10	IDLER GEAR BUSHING	1	1
E-15	BEARING RETAINER PLATE	1	1
E-20 ASSY	* BYPASS VALVE CARTRIDGE W/O-RING	1	1
3/8-16Tx1-1/4L	CAP SCREW	10	10
3/8-16Tx3-1/4L	CAP SCREW	2	2
1/4-20Tx1-1/4L	CAP SCREW	6	6
D-21	* STRAINER SCREEN	1	1
6227-17	* O-RING FOR BYPASS VALVE (BOTTOM)	1	1
568-118	* O-RING FOR BYPASS VALVE (TOP)	1	1
6230-14	* O-RING FOR COVER	1	1
VC-20	* COMPLETE DRIVE COUPLING	1	1
FD-20	* COUPLING INSERT	1	1
12 PLUG	1/2" PIPE PLUG	1	0
5 KEY	DRIVE GEAR KEY	1	1
61 KEY	SHAFT KEY, DRIVE END	1	1
L-3	LABEL PLATE	1	1
L-7	INSTRUCTION PLATE, RED	1	1
105 CUP	BLEEDER CUP	1	1
3816114	SOCKET HEAD SET SCREW	4	4
10-32T X 1/2L	MACHINE SCREW - FILLISTER HEAD	8	8

*** RECOMMENDED SPARE PARTS**

NOTE: When ordering parts, the model number and serial number of the pump in which the parts will be used **MUST** be given.
 (See metal name plate on pump for this information.)