

EFFECTIVE:
 JULY 1, 2008

PARTS LIST FOR EG-1Z AND EC-HZ PUMPS

QTY PER PUMP:

<u>PART #</u>	<u>NAME OF PART</u>	<u>EG-1Z</u>	<u>EC-HZ</u>
* E-100Z	** EG-1Z SHAFT SEAL ASSEMBLY	1	0
* E-100HZ	** EC-HZ SHAFT SEAL ASSEMBLY	0	1
E-1	MAIN HOUSING	1	0
E-1H	MAIN HOUSING	0	1
E-2	GEAR END COVER	1	0
E-2H	GEAR END COVER	0	1
E-3	MOUNTING SPACER W/STUD	4	4
* EG-5	DRIVE GEAR	1	0
* EC-5H	DRIVE GEAR	0	1
* EG-6	IDLER GEAR W/BUSHING E-10	1	0
* EC-6H	IDLER GEAR W/BUSHING E-10	0	1
* E-9	IDLER GEAR SHAFT	1	1
E-10	IDLER GEAR BUSHING	1	1
E-15	BEARING RETAINER PLATE	1	1
* E-20 ASSY	** BYPASS VALVE CARTRIDGE W/O-RING	1	0
* E-20H ASSY	** BYPASS VALVE CARTRIDGE W/O-RING	0	1
3/8-16Tx1-1/2L	CAP SCREW	8	8
3/8-16Tx3-1/2L	CAP SCREW	4	4
10-32Tx1/2L	SCREW, FILLISTER HEAD	8	8
* E-21	STRAINER SCREEN	1	1
6227-17	** O-RING FOR BYPASS VALVE (BOTTOM) FOR E-20	1	1
568-118	** O-RING FOR BYPASS VALVE (TOP) FOR E-20H	1	1
568-026	** O-RING FOR BYPASS VALVE (BOTTOM) FOR E-20H SLEEVE	0	1
* 6230-28	O-RING FOR E-2 COVER	1	1
* VC-20	COMPLETE DRIVE COUPLING	1	0
* FD-20	INSERT ONLY FOR COUPLING	1	0
* VC-30	COMPLETE DRIVE COUPLING	0	1
* FD-30	INSERT ONLY FOR COUPLING	0	1
12 PLUG	1/2" PIPE PLUG, SQUARE HEAD	1	0
34 PLUG	3/4" PIPE PLUG, SQUARE HEAD	0	1
5 KEY	DRIVE GEAR KEY	1	1
61 KEY	SHAFT KEY, DRIVE END	1	1
L-3	LABEL PLATE (SERIAL NO.) RED	1	1
L-7	INSTRUCTION PLATE, RED	1	1
E-51 (OPTIONAL)	ADAPTOR PLATE, ENGINE, WITH CAP SCREWS	1	1
E-52 (OPTIONAL)	FOOT MOUNT BRACKET, WITH SPACERS	1	1
105 CUP	BLEEDER CUP	1	1
3816114	SOCKET HEAD SCREW SET FOR SPACER	4	4

* **RECOMMENDED SPARE PARTS**
 ** **LIQUID BEING PUMPED MUST BE SPECIFIED**

NOTE: When ordering parts, the model number and serial number of the pump in which the parts will be used **MUST** be given.
 (See metal name plate on pump for this information.)